Johnson Noise

Eric Chen, MIT Department of Physics, 11/20/2018


History

 1928 Bell Labs: John B. Johnson measures a thermally varying electrical noise experimentally

 Colleague Harry Nyquist publishes a theoretical explanation soon after

Thermal Noise

 Thermal agitation of charge carriers produces fluctuation of voltage across a resistor



Time

Interesting Features

 This noise depends only on the resistance and temperature of the system

 Noise doesn't depend on what type of charge carrier, or the resistor material


In this Lab:

 We measure Johnson noise for varying resistances and temperatures


 k (Boltzmann's constant) was not known individually


 In this lab, k and centigrade temperature of absolute zero can be extracted from measurements of Johnson noise

Theory




- ullet System temperature T
- ullet Resistances R_I and R_{II}







 Each band df contributes a average voltage difference to the overall circuit voltage:




• Each small frequency band of oscillation df contributes an average amount of current:




• Each band df contributes an amount of average power through a resistor of resistance R_i :






 By the 2nd Law of Thermodynamics, the power passed through each resistor is equal:

$$dP_I = dP_{II} = dP$$




 Using these relationships, the total average voltage contribution over all frequency bands for a system at temperature T can be derived:





How do we measure this voltage?


Experimental Setup





Schematic
















 How do we measure a single voltage for an oscillating noise signal on our oscilloscope?



Time

• We measure the root mean square V_{rms} of the signal:



Time

Obtaining Noise from Measurement

 Our setup modifies the noise from the resistor on the Johnson Box

 How do we extract the original noise voltage from our measured voltages?

- Separate amplifier noise
- Determine gain


Amplifier Noise

 Experimental setup contributes electrical noise to the measured value

 How do we isolate the voltage noise contribution from the resistor on the Johnson Box? ullet We measure the sum of the noise produced by our resistor and the amplifier V_R

ullet We measure the sum of the noise produced by our resistor and the amplifier V_R

ullet We measure the noise produced with the resistor shorted out $V_{\mathcal{S}}$




 \bullet We measure the sum of the noise produced by our resistor and the amplifier V_R


ullet We measure the noise produced with the resistor shorted out $V_{\mathcal{S}}$

• We can subtract these independent sources in quadrature to extract the isolated noise of the resistor: $V^2 = V_R^2 - V_{\varsigma}^2$

Gain Calibration

• Amplifier and band-pass filter transform the original average voltage noise produced by a frequency band df by a multiplicative factor






Gain Calibration

• Amplifier and band-pass filter transform the original average voltage noise produced by a frequency band df by a multiplicative factor

 Knowing this factor allows us to extract the raw noise from measured noise



ullet Plugging in the expression derived for dV_{noise}

$$dV_{measured} = 2\sqrt{kRT}g(f)df$$

ullet Plugging in the expression derived for dV_{noise}

$$dV_{measured} = 2\sqrt{kRT}g(f)df$$

Integrating over a finite frequency spectrum:

$$V_{measured} = 2\sqrt{kRT} \int_{a}^{b} g(f)df$$

 Square our voltage measurement in order to manipulate it in quadrature

$$V_{measured}^2 = 4kRT \int_a^b g^2(f)df$$

 Square our voltage measurement in order to manipulate it in quadrature

$$V_{measured}^2 = 4kRT \int_a^b g^2(f)df$$

 Introduce a resistance dependent reducing factor in the gain to model the capacitance of the connecting wires in our setup

$$V_{measured}^2 = 4kRT \int_a^b \frac{g^2(f)}{\sqrt{1 + (2\pi fRC)^2}} df$$

 So, the effect of amplification and filtering on the raw noise is quantified by defining a gain factor G that differs for each resistor

$$V_{measured}^2 = V_{noise}^2 G$$

• Where:

$$G = \int_{a}^{b} \frac{g^{2}(f)}{1 + (2\pi fRC)^{2}} df$$


 Factor G relating post and pre amplification noise is then determined for each resistor as follows:

$$G = \int_{0kHz}^{90kHz} \frac{g^2(f)}{1 + (2\pi fRC)^2} df$$


 Factor G relating post and pre amplification noise is then determined for each resistor as follows:

$$G = \int_{0kHz}^{90kHz} \frac{g^2(f)}{1 + (2\pi fRC)^2} df$$

• Value of $g^2(f)$ is determined by measuring the gain of our system without a resistor on the box



 Gain integral is calculated using numerical integration methods like the trapezoid rule:



Gain Integral Uncertainty

Depends on the method of integration used

 We use the Trapezoid rule and Simpson's rule for integration, and compare:

$$\sigma_{G,method} = \frac{G_{trapezoid} - G_{simpson}}{G_{trapezoid}} \approx \pm 0.6\%$$

Gain Integral Uncertainty

Depends on capacitance of the setup

Parallel wires can produce a capacitance

 We measure two sets of resistor varying data, changing the wiring setup in between Taking the ratio of calculated gains for each setup gives an estimate of capacitance fluctuation:

$$\frac{G_{setup1}}{G_{setup2}} pprox \pm 9.0\%$$
 $\sigma_{G,capacitance} pprox \pm 7.5\%$

Noise Measurement Procedure

1) Resistance is measured for resistors in a range of 10 kohm to 1000 kohm

Noise Measurement Procedure

- 1) Resistance is measured for resistors in a range of 10 kohm to 1000 kohm
- 2) RMS Voltages are measured for each resistor both in circuit and shorted out of the circuit

Noise Measurement Procedure

- 1) Resistance is measured for resistors in a range of 10 kohm to 1000 kohm
- 2) RMS Voltages are measured for each resistor both in circuit and shorted out of the circuit
- 3) Measured voltages subtracted in quadrature are related to pre-amplification noise voltage by calculating G for each resistor


Boltzmann Constant

 Using the derived relationship between measured and original noise for each resistor:

$$V^2 = 4kRTG$$

 Boltzmann Constant k is extracted for each resistor value:

$$k = \frac{V^2}{4TGR}$$



Uncertainties

• Resistor resistance: σ_R

• Capacitance: $\sigma_{G,capacitance}$

• Gain integral: σ_G

• Squared voltage: σ_{V^2}

Resistance

 Limited by the accuracy of the our multimeter (Hewlett Packard 972A):

Resistance

Range	Resolution	971A	972A	973A	Test Current	Test Voltage
400 Ω	100 mΩ		0.2% + 1		.8mA	< 3.2 V
4 kΩ	1Ω				<80 µA	<1.1V
40 kΩ	10 Ω	0.5% + 1			<10 µA	
400 kΩ	100 Ω				<1.1 µA	
4 MΩ	1 kΩ		0.5% + 1		<110 nA	
40 MΩ	10 kΩ	1% + 1		\ \TTO IIA		

Resistance

 Applying this to each resistance based on which range it falls within:


$$\sigma_R \approx \pm 0.4 \%$$

Gain Integral Uncertainty

 Combining the numerical integration method and capacitance contributions:

$$\sigma_G \approx \pm 7.0\%$$

 Uncertainty in capacitance dominates as resistor values get higher



Squared Voltage

 Squared voltage is resistor dependent and is given by:

$$V^2 = V_R^2 - V_S^2$$

Squared voltage is given by:

$$\sigma_{V^2} = \sqrt{var(V_R^2) + var(V_S^2)} \approx \pm 6.5e^{-7} (volts)$$

Boltzmann Error Propagation

 Propagating these sources of error in quadrature through the equation:

$$k = \frac{V^2}{4TGR}$$


We obtain values for each resistor:

$$\sigma_k \approx \pm 0.10e^{-23} \left(\frac{J}{K}\right)$$

Uncertainty in Average k

- We use a Monte Carlo simulation to raffle k values within a distribution of width $2\sigma_k$
- We find the average k value for each set of points
- The standard deviation of the raffled average-measured average difference is the uncertainty on our average:

$$\sigma_{k,mean} = \pm 0.018e^{-23} \left(\frac{J}{K}\right)$$




Absolute Zero

 Centigrade temperature of absolute zero can be extracted:

- For a single 100 (kOhm) resistor, noise is measured over a range of temperatures
- We then plot:

$$\frac{V^2}{4GR}$$
 vs. T



Liquid Nitrogen Data Point


 Follows a slightly different linear relationship than other points

 Seems suspicious - what steps were taken to mitigate systematic uncertainty?

Liquid Nitrogen Data Point

- Resistor was immediately immersed in bath
- Resistor was allowed significant time to come to equilibrium with bath temperature
- Glass container used to mitigate capacitance effect from box-container contact
- 40 V_R and V_S measurements were taken as opposed to 10 for all other temperatures
- Performed the measurement twice yielded very similar results

1 × e⁻²¹ Nitrogen Measurement Excluded



Absolute Zero Uncertainty

 Using the uncertainty in the linear fit given by the covariance matrix returned, we calculate:

With Nitrogen: $\sigma_{T_0} \approx \pm 37.0 \ C^{\circ}$

Without Nitrogen: $\sigma_{T_0} \approx \pm 32.0 \ C^{\circ}$

Summary

 From our Johnson noise measurement, we extract the following values for our Boltzmann constant:

$$k_{extracted} = (1.34 \pm 0.020)e^{-23} \frac{J}{K}$$

$$k_{accepted} = 1.38e^{-23} \frac{J}{K}$$

Summary

We extract the following values for absolute zero:

```
With Nitrogen:  \begin{cases} \text{Extracted: } (-465.0 \pm 37.0) \ C^{\circ} \\ \text{Accepted: } -273.15 \ C^{\circ} \end{cases}
```

Without Nitrogen: $\begin{cases} \text{Extracted:}(-236.0 \pm 32.0) \ C^{\circ} \\ \text{Accepted:} -273.15 \ C^{\circ} \end{cases}$

Applications

 Johnson noise is significant when dealing with high precision electronics application using radio frequency technology

Cellphones, wifi, radio, and much more

Thank you!